Model Name

Versions

Features

Olight M21-X Warrior (Use Cree XM-L LED)

Tough. Versatile. Multi-functional. Easy to operate. ends give added effectiveness when used for self-defense.

Like the soldiers it's made for the Olight M21-X Warrior a carefully honed combat gear. The M21-X's rugged body structure, stainless steel striking bezel, blindingly

bright strobe light and multiple functions give it a strength and versatility never seen before in the hand-held lighting market. The M21-X Warrior is all the lighting tool you need in the battlefield or on the job. Bright, rugged, and flexible the M21-X's multiple output levels and modes lend it a versatility and durability that make it the ideal tool for any task. The M21-X Warrior is a great choice for personal protection; the blinding light and crenellated striking bezel on both

Olight M21-X Warrior Cree XM-L LED

Output & Runtime ---Low Level: 20 lumens /36 hrs

--- Medium Level: 200 lumens /3h45min

---High Level: 600 lumens /1h20min

---Strobe: 10Hz (frequency)

Batteries: 2 x CR123A or 1 xl 8650. Dimension: Length: 145.5mm (5.7");

> Bezel Diameter: 40.2mm(1.6"): Body Diameter: 24.8mm(0.98");

Weight: 123g (4.3 oz) exclude batteries Peak Beam Intensity: 14400cd

Impact Resistance: 2 meters

Water proof: 2 meters /30minutes Accessories: Includes one holster, one lanvard, four

spare O-rings, one rubber boot, one battery magazine. two batteries, one diffuser and one cover ring.

- Max 600 lumens.
- Max 240 meters long throw.
- for easy momentary or click to lock on.

World-class super bright Cree XM-L LED.

- Auto memorization of specific function for instant access.
- · Removable stainless steel striking bezel.
- electrical components. Ergonomic design with solid structure for easy operation.

Superior heat sink that disperses heat to protect LED and

· Tactical momentary-on forward switch, protruding switch

- Full orange peel reflector for flawless wide beam.
- · Rugged indestructible aluminum body with anti-scratching type III hard anodization.

Operation Introduction



No	Name	No	Name
1	Striking Bezel	7	Pocket Clip
2	XM-L LED	8	Cigar hold
3	Head(Upside)	9	Power Siwtch
4	Reflector	10	Tailcap
5	Head(Downside)	11	Battery Magazine
6	Battery Tube	12	Battery

For momentary light, gently press (no click) power switch in the tailcap.

For constant light, fully press (click) power switch in the tailcap.

To switch functions, click on the light, loosen the head by 1/8 of a circle and then tighten it down, the light will move to the next function. Repeat the same operation for further functions.

Usage and Maintenance

Use quality batteries so as not to damage the light due to leaks or other self-destructive possibilities. Remove batteries when light will not be used for an extended period or if batteries are discharged. When using Li-Ion batteries Olight only recommends the use of 'protected' batteries that limit charge and disharge.

Clean contacts, threads and O-rings of the flashlight with clean cloth from time to time when necessary. Should flickers or doesn't light up this is the most likely cause. If flashlight is used in wet environment, lubricate O-rings frequently to maintain watertight seal. After prolonged exposure to moisture, the bezel, lamp, and batteries should be removed, inspected, and cleaned if necessary.

Optional Accessonies



Battery Magazine



Switch (Optional)





Lanyard





Holster

Standard: White Diffuser Optional: Red , Green, Blue Filter